






pozice	objednací číslo	název	počet
1	REBV3000-1	power plug	1
2	REBV3000-2	cable set	1
3	REBV3000-3	wirepress board	1
4	REBV3000-4	terminal block	1
5	REBV3000-5	capacitor	1
6	REBV3000-6	internal inductor(white)	1
7	REBV3000-7	internal inductor(black)	1
8	REBV3000-8	push switchbutton	1
9	REBV3000-9	switch	2
10	REBV3000-10	heatshrinkabletube	1
11	REBV3000-11	doubleswitch	1
12	REBV3000-12	speed controlboard	1
13	REBV3000-13	speed switch button	1
14	REBV3000-14	house vest(left)	1
15	REBV3000-15	handleshcckabsorption	1
16	REBV3000-16	handlecover	1
17	REBV3000-17	up handle house	1
18	REBV3000-18	locknut M6	2
19	REBV3000-19	coverboard	1
20	REBV3000-20	insert 4.8x0.6	1
21	REBV3000-21	tapping screw ST3X20	4
22	REBV3000-22	down buttonhouse	1
23	REBV3000-23	tapping screw ST3.5X14	3
24	REBV3000-24	left house	1
25	REBV3000-25	selector lever	1
26	REBV3000-26	conversationboard	1
27	REBV3000-27	screwM4	2
28	REBV3000-28	commonmode inductor	2
29	REBV3000-29	carbon brush	2
30	REBV3000-30	screwST3X8	2
31	REBV3000-31	brush holder	2
32	REBV3000-32	locknut M5	2
33	REBV3000-33	up motorcover	1
34	REBV3000-34	screwM5X80	2
35	REBV3000-35	dampingblock	1
36	REBV3000-36	rotor	1
37	REBV3000-37	flash washer Ø5	2
38	REBV3000-38	spring washerØ5	2
39	REBV3000-39	stator	1
40	REBV3000-40	bearing 608	2
41	REBV3000-41	bearing sleeve	1
42	REBV3000-42	down motorcover	1
43	REBV3000-43	dampingring	1
44	REBV3000-44	suction fan	1
45	REBV3000-45	flat washerØ8	1
46	REBV3000-46	locknut M8	1
47	REBV3000-47	fanplug	1
48	REBV3000-48	blade	1
49	REBV3000-49	spring washerØ4	3
50	REBV3000-50	screwST4X14	3
51	REBV3000-51	removable suck leafmouth	1
52	REBV3000-52	littlewheel	2
53	REBV3000-53	flatwasherØ3.5	2
54	REBV3000-54	littlewheelcover	2

55	REBV3000-55	rightwheel	1
56	REBV3000-56	leftwheel	1
57	REBV3000-57	downwide pipe	1
58	REBV3000-58	steelwire	1
59	REBV3000-59	upwide pipebuckle	1
60	REBV3000-60	screwM4X22	2
61	REBV3000-61	steelwire spring	1
62	REBV3000-62	openingblockcircleΦ2.5	1
63	REBV3000-63	switchpushlever	1
64	REBV3000-64	pushleverspring	1
65	REBV3000-65	upwine pipe	1
66	REBV3000-66	righthouse	1
67	REBV3000-67	righthousevest	1
68	REBV3000-68	lockingbolt	1
69	REBV3000-69	lockingplate	1
70	REBV3000-70	elastiepinΦ3	2
71	REBV3000-71	lockingbutton	1
72	REBV3000-72	dustremovingwindow	1
73	REBV3000-73	rotaryswitch	1
74	REBV3000-74	screwM4X40	1
75	REBV3000-75	removable dustcollectionframe	1
76	REBV3000-76	dustcollectionbag	1