




RET 4015			
Pozice	Obj.číslo	Popis	Počet
1	WR8001-1400-700-01-400/6/R	blade assembly (right)	1
2	GB845-85/M8x40	screw bolt	2
3	WR8001-1400-700-01-400/6/L	blade assembly (left)	1
4	GB845-85/M8	Locknut	2
5	GB845-85/ST6x25	screw	4
6	GB845-85/ST4x16	screw	18
7	WR8025-1500-700-01	guard plate	1
8	WR8018-1400-400-09	connection shaft	1
9	WR8031-1800-300-02	Lower casing seat	1
10	WR8031-1800-300-01	main housing	1
11	WR8001-1400-300-01	housing	1
12	WR8001-1400-300-24	Cable fix board	1
13	WR8002-1400-300-02	housing cover	1
14	WR8001-1400-800-01	No.1 Sponge	1
15	WR8001-1400-300-14	knob	4
16	GB845-85/M6x45	coach screw	4
17	WR8011-1500-700-04	No.2 rod	2
18	WR8001-1400-300-38	cable clamp	2
19	WR8011-1500-700-02	No. 1 rod	1
20	GB845-85/M6	Locknut	6
21	WR8001-1400-700-12A	6 wave washer	6
22	GB845-85/M6x32	coach screw	4
100	RET4015-100	Gear box assembly	1
101	WR8025-150-400-03	gear box right	1
102	WR8001-1400-700-13	sealing ring baffle	2
103	WR8001-1400-400-08	sealing ring	2
104	WR8001-1400-400-06	bearing	2
105	WR8001-1400-700-10	washer	2
106	WR8018-1500-400-08	worm gear shaft	1
107	GB/T1096-2003	flat key	1
108	WR8025-1500-400-01	worm gear	1
109	GB/T276-1994/608Z	bearing	1
110	WR8011-1500-400-02	worm gear	1
111	WR8001-1400-400-09	gearbox sealing strip	1
112	WR8025-150-400-04	Gear box left	1
113	WR8001-1400-400-08-1	"O" ring	1
114	GB845-85/M10x10	screw	1
115	GB845-85/M6x18	screw	8
116	WR8001-1400-400-10	Sealing ring	1
117	WR8001-1400-400-11	splined hub	1
118	GB/T276-1994/16100Z	bearing	1
119	GB/T276-1994/6000Z	bearing	1
200	RET4015-200	Motor assembly	1
201	WR8020-1200-300-06	motor frame	1
202	WR8031-1800-300-03	sponge	1
203	WR8031-1800-500-02	rotor assembly	1
109	GB/T276-1994	bearing	1

204	GB845-85/22	Wave washer	1
205	GB845-85/ST4x70	screw	2
206	GB845-85/4	Elastic gasket	2
207	WR8031-1800-500-01	stator assembly	1
208	WR8025C-1500-500-03	circular inductor	2
209	WR8011-1500-500-03	Thermal protector	1
210	WR7025-1500-300-01	motor housing	1
211	WR8001-1400-500-06	capacitance	1
212	WR8001-1400-600-02	carbon brush holder	2
213	WR8001-1400-600-01	carbon brush	2
214	GB845-85/ST3x12	screw	2
300	RET4015-300	H shape switch assembly	1
301	WR8001-1400-300-27	main handle left	1
302	WR8001-1400-400-28	trigger spring	1
303	WR8001-1400-300-32	trigger	1
304	WR8001-1400-400-29	handle button spring	1
305	WR8001-1400-300-33	switch button	1
306	WR8001-1400-300-28	main housing right	1
307	WR8001-1400-700-06H	No. 3 rod	1
308	WR8001-1400-300-29	handle press plate	1
309	GB845-85/ST4x20	screw	4
310	WR8001-1400-300-31	secondary handle right	1
311	WR8001-1400-300-30	secondary handle left	1
312	WR8001-1400-500-05H	power cord& plug	1
313	WR8025-1500-500-01H	Connctet power cord	1
314	WR8001-1400-300-25	power cord sleeve	1
315	GB845-85/ST4x18	screw	4
316	KND2-12/2	Rocker swtich	1
400	RET4015-400	wheel assembly	1
401	WR6005-1500-300-09	wheel cover	2
402	GB845-85/2x16	R pin	2
403	GB845-85/10.5x20x1.5	φ10 flat key	2
404	WR8018-1500-300-11	wheels	2
405	WR8001-1400-700-12	φ6 washer	1
406	WR8801-700-03	wheel holder assembly	1
406-1	WR8028-1500-700-10	iron wheel holder left	1
406-2	WR8011-1500-700-07	iron wheel holder right	1
406-3	WR8011-1500-400-05	wheel fix shaft	1
407	RET4015-407	Release ring	1
408	WR8028-1500-300-17	wheel adjust bracket	1
409	WR8001-1400-400-27	iron wheel adjust spring	1
410	WR8028-1500-400-03	iron wheel adjust shaft	1
411	GB845-85/ST4x16	screw	2
412	GB845-85/M6x35	screw	2